

Formatting your USB stick for first time use with your MC230E:

Simply inserting the USB stick into your Memory Craft 200E while the MC200E is powered on will automatically create a main folder called EMB and a sub-folder called **Embf**. You will see a notification on the LCD screen indicating not to remove the stick and not to power off the machine during this process.

When saving your embroidery files onto the USB stick, you can save them in the **Embf** folder, or you can create custom named folders inside of the EMB folder only.

You also have the option to open a built in design, go into the Edit mode, then touch the Save icon (folder with arrow pointing folder), choose to save the design to the USB memory stick, this will automatically save the design into the Embf folder, or if you have set up custom folders on the USB you will have the option to save the design into one of those folders.

The maximum size USB stick to use with this machine is 2 GB. Please note that Janome has not been able to test all brands available, so some USB sticks may be incompatible.

